

Recipe for Bituminous Cement used on No 473.

- pitch. 250 lbs.
- tar. 6 gallons. (equal 60 lbs or more)
- cement. 360 lbs.
- lime. 56 lbs.
- resin. 14 lbs.

The pitch is first put into the pot and heated sufficiently to make it liquid, next add the tar and keep the fire going, when sufficiently hot add cement slowing sifting it through the fingers, and stirring it well all the time, next add lime, in very small quantity, stir well and watch that the mixture does not boil over, if too thick, thin down as required by common mineral oil. Make the mixture thoroughly hot, pour on and spread with a half worn mop.

RECEIVED  
FEB 10 1911  
OFFICE OF THE REGISTER  
HULL

COCHRANE & SONS  
IRON & STEEL  
SHIPBUILDERS  
& ENGINEERS  
SELBY

LLOYD'S REGISTER  
OF SHIPPING  
HULL

LLOYD'S REGISTER  
OF SHIPPING.  
8-FEB 1911  
HULL



© 2020

Lloyd's Register  
Foundation

W856-0180

Referred to the Chief Ship Surveyor.

LLOYD'S REGISTER  
OF SHIPPING  
8-18814

LLOYD'S REGISTER  
OF SHIPPING  
FEB. 1911  
HULL

LLOYD'S REGISTER  
OF SHIPPING  
8-18814



Lloyd's Register  
Foundation

© 2000  
Lloyd's Register  
Foundation

Receipt for Portland Cement used on No 412

Engine  
L  
TONNAGE