

Engines No. 882.

Spare Gear List.

Auxiliary Engine & Compressors.

	<u>No. off.</u>
earing Bushes bottom halves.	1 set.
" Oil Rings.	1 set.
connecting Rod Brasses.	1 "
Washer.	1
Body & Valve.	1
.	3
b	1
n Tubes.	2
tor Gauge & Sight Feed Glasses.	1 set.
nd Brasses.	1 "
ulating Tap.	1
ump complete.	1
Nipples.	3
Rings.	2
or Safety Valve.	4
	1 set.
	1 "
essor	
Rings for L.P.	1 set
" " H.P.	1 "
pin Bush.	1
ng Rings.	2
or Crankpin Oiler.	1
" "	3
lves, seats and springs.	2
" " "	2
ap Washers.	4
s & Box Keys.	9



© 2018

Lloyd's Register
Foundation