

in the bearings in the stern tube, is the space charged with a plastic material insoluble in water and non-corrosive
are fitted, is the shaft lapped or protected between the liners ✓

Length of stern b

GRAMS:
REGISTER.

TELEPHONE:
Nº. 615.

Lloyd's Register of British & Foreign Shipping.

VEERHAVEN W. Z. 19. — ROTTERDAM.

LETTERS TO BE
ED TO:
S TO LLOYD'S
VER.
DAM.

LLOYD'S REGISTER,
LONDON.

REC'D 9 JUN 1910

S. ANSP.

10

8 June 1910.

The Secretary,

London.

Sir,

In reply to your yesterday's classing letter respecting the S/S "Moordrecht" I beg to state that this Superheater is found to be always in use together with the boiler, which I have stated to the best of my ability by answering the question "can the superheater be shut off ^{and} ~~from~~ the boiler worked separately" with no.

The steam on its way from the boiler to the engines has always to pass through the superheater.

I may however explain that in case one of the tubes in this superheater should give out it will only mean a stoppage for a few minutes to disconnect it, to draw the three or four superheating tubes belonging to the same leader from the collectors and to plug the holes in the collectors with the special plugs on board for that purpose.

I have retained the first entry certificates until I hear from you again.

The H.P. slide valve is a piston valve.

I am, Sir,

Your obedient servant,

M. F. D. Van Oosteren

© 2020



Lloyd's Register
Foundation

WILDL-0097

Thickness of shell plates ✓ Material ✓ Description of longitudinal j
Diameter ✓ Length ✓

Diameter of flue ✓ Material of flue plates ✓

