



Diagram illustrating the furnace assembly and its components, including labels for various parts and connections:

- ALL PIPES AND FITTINGS TO BE KEPT CLEAR OF FURNACE FRONT MOUNTINGS & CONTROLS.
- THERMOMETER.
- F347
- N.O.S.E.
- BURNER.
- HAND PUMP DISCH. TO 'U' TUBE FROM HAND PUMP DISCH. FILTER.
- 'U' TUBE TO BURNER
- N.O.S.E.

O/Nº 5027.

SCALE :- $\frac{3}{8}" = 1 \text{ FOOT.}$

SHEET № 2

HARLAND & WOLFF LTD.
BELFAST

No. Llandaff Castle 5027

TITLE Oil fuel discharges (2)

DATE APPROVED 1.3.39

"Llandaff Castle"

Belfast Rpt 12394

X1193-0075



© 2021

Lloyd's Register
Foundation