

Engine No. K.9/A

SPARE LOOSE SPRINGS.

Used For	Pattern No	Drg. No	Dia. of wire	Mean Dia.	Free Length	No. of coils
Fuel valve	26344	20654	18	80	175	5½
Inlet valve	26439	20361	14	164	393	10
" "	26440	20361	11	120	315	11
Exhaust valve	26439	20478	14	164	393	10
" "	26440	20478	11	120	315	11
Starting valve	26681	20673	11	96	258	10
" "	27328	20673	8	96	119	3.5
Safety valve on cylinder cover	30275	4286	14	72	174	6
Opening gear for exhaust valve	30180	20689	12	64	202	10
Air compressor H.P. safety valve	6090	3651A	10	26	180	13
Air compressor M.P. safety valve	4392	3916	9	28	164	14
Air compressor L.P. safety valve	4393	4167	7	27	135	14
Automatic shut off valve for air	26241	19217	5	49	165	13
Starting air slide	30376	20715	5	48	190	16
Engaging lever for governor	30620	21034	5	25	30	2
Fuel pump discharge valve	30658	7577	4	26	60	6½
Control valve for starting air	11076	20866	2.5	14	57	9
Air control valve reversing gear	6247	20877	3	24	53	7
Oil hand pump discharge valve	6240	20863	2	24	50	6




© 2019

Lloyd's Register Foundation

W230-0200 (1/3)

No. off	Used For	Pattern No.	Drg. No.	Dia. of wire	Mean dia.	Free Length	No of coils
6	N.R.valve for fuel valve	7757	7226	2	12	35	8
1	Handle for air control valve	102	49	2	11	34	10
6	N.R.valve for fuel oil pipe	1783	4675	2	11	22	5
2	Handle for manoeuvring gear	102	49	2	11	34	10
9	Fuel pump suction valve	30659	7577	1.5	18	42	10
1	Fuel pump relief valve	12586	1424	2	14	48	10
1	Governor spring box	6396	4436	1.5	9	50	11
2	Oil hand pump suction valve	6239	20863	1	20	60	6
1	Governor emergency weight	6395	4436	0.8	9	32	10
1	Governor stopper pin	6397	4436	0.6	5	12	6
6	Indicator Gear	26939	21026	5	37	100	10
6	" "	26950	21026	2.5	17	20	3½
15	Upper platform for engine	26762	20713	10sq.	50	112	5
2	Gear for starting slide	31324	7689	3	20	58.5	17
6	Oil guard for piston rod	27353	20550	1	9	665	355
6	Indicator gear	168	21053	1.5	24	85	50
2	Air compressor H.P. suction & delivery valve	4850A	4824A	1 thk.	42 ext.	18	2
7	Air compr.M.P.suction & delivery valve	4172A	4579A	1.5thk	71.5 ext.	22	2



No. of	Used for	Pattern No.	Dwg. No.	Dia. of wire	Mean dia.	Free Length	No. of Coils
6	Air compr.L.P. suction valves	4171A	4579A	1 thk.	71.5 ext.	22	2
6	N.R. valve for 20 m/m blast air pipe	6513A	4614A	1 "	34 "	13	2
1	N.R.valve for main blast air pipe	6513A	4614A	1 "	34 "	13	2
1	N.R.valve for air outlet	4900A	4611A	1 "	47 "	22	2



© 2019

Lloyd's Register
Foundation

W230-0200 (3/3)