

SPECIFICATION OF SPARE PARTS

for

DIESEL-POLAR-MOTOR-COMPRESSOR, TYPE L C 2 C.

Exhaust valve with spring plate and key

Fuel valve needle

Needle guide

Pulveriser

Sprayers

Sprayer nut

Glass bulbs for fuel pump

Valves for lowpressure air pump

Suction valves for highpressure air pump

" " " " L. P. " "

Delivery valves for highpressure air pump

Metal cone for injection air receiver

Ebonite cones for starting air receiver

Small cones for air receiver

Piston rings for working piston

Piston rings for highpressure piston

Piston rings for lowpressure piston

} for injection air compressor

Piston rings for highpressure piston for working compressor

Piston rings for lowpressure piston for working compressor

Various springs for for exhaust valve, fuel valve needle, suction valve and air pump

Various packing rings and packing material

Copy certified

Atkinson



© 2020

Lloyd's Register
Foundation